




# 6\_Segno Ceiling track systems

Ceiling beams can be used when the track can be fastened to an overhead load-bearing structure. Always remember to measure the extremities and the centre of the door space carefully, and then indicate these figures in your order.



## 1-way ceiling track




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 6 \text{ cm}$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 3 \text{ cm}$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$





Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 6 \text{ cm} : 2$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$




## 2-way ceiling track




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 5 \text{ cm} : 2$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$





Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 10 \text{ cm} : 4$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$





3-way ceiling track




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 11 \text{ cm} : 3$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$



Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 22 \text{ cm} : 6$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$



Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 14 \text{ cm} : 3$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} - 5,8 \text{ cm}$




# 6\_Segno Wall track systems


Wall beams should be used to fasten the panels directly to the wall.  
The depth of the beam is determined by the number of tracks.

**Please specify in your order if the track is to be positioned flush with the ceiling.**



## 1-way wall track





Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 6 \text{ cm}$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} + 2 \text{ cm}$   
 $H_{\text{total composition}} = H_{\text{panel}} + 5,5 \text{ cm}$




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 3 \text{ cm}$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} + 2 \text{ cm}$   
 $H_{\text{total composition}} = H_{\text{panel}} + 5,5 \text{ cm}$




Width calculations  
 $W_{\text{panel}} = W_{\text{door space}} + 6 \text{ cm} : 2$   
 Height calculations  
 $H_{\text{panel}} = H_{\text{door space}} + 2 \text{ cm}$   
 $H_{\text{total composition}} = H_{\text{panel}} + 5,5 \text{ cm}$




2-way wall track



Width calculations  
 $W \text{ panel} = W \text{ door space} + 8 \text{ cm} : 2$   
 Height calculations  
 $H \text{ panel} = H \text{ door space} + 2 \text{ cm}$   
 $H \text{ total composition} = H \text{ panel} + 11,7 \text{ cm}$



Width calculations  
 $W \text{ panel} = W \text{ door space} + 17 \text{ cm} : 4$   
 Height calculations  
 $H \text{ panel} = H \text{ door space} + 2 \text{ cm}$   
 $H \text{ total composition} = H \text{ panel} + 11,7 \text{ cm}$




# 6\_Segno


Pocket doors with wood jamb

Segno panels can be inserted into hidden counterframes.


## Single pocket door




Width calculations  
 $W \text{ panel} = W \text{ door space} - 2,5 \text{ cm}$   
Height calculations  
H panel = depends on the brand of the counterframe  
(can vary from -4 cm to -3 cm from the floor/below-track height)




## Scorrimento a scomparsa doppio




Width calculations  
 $W \text{ panel} = W \text{ door space} - 3 \text{ cm} : 2$   
Height calculations  
H panel = depends on the brand of the counterframe  
(can vary from -4 cm to -3 cm from the floor/below-track height)



## Scorrimento a scomparsa con doppio binario



Width calculations  
 $W \text{ panel} = W \text{ door space} + 3 \text{ cm} : 2$   
Height calculations  
H panel = depends on the brand of the counterframe  
(can vary from -4 cm to -3 cm from the floor/below-track height)





# 6\_Segno

Pocket doors without jamb



## Single pocket door

Width calculations  
W panel = depends on the brand of the counterframe  
(variable from + 1,6 cm to + 3,5 cm compared to the size of the door space)  
Height calculations  
H panel = depends on the brand of the counterframe  
(variable from - 0,7 cm to - 1 cm from the height of the door space)



## Double pocket door

Width calculations  
W panel = depends on the brand of the counterframe  
(variable from + 1,6 cm to + 3,5 cm : 2 compared to the size of the door space)  
Height calculations  
H panel = depends on the brand of the counterframe  
(variable from - 0,7 cm to - 1 cm from the height of the door space)





# 6\_Segno

Pocket doors with aluminium jamb



## Single pocket door

Width calculations  
L panel = L door space - 3,8 cm  
Height calculations  
H panel = depends on the brand fo the counterframe  
(can vary from - 4 cm to - 3 cm from the floor/below-track height)







## Double pocket door

Width calculations  
L panel = L door space - 3 cm : 2  
Height calculations  
H panel = depends on the brand of the counterframe  
(can vary from - 4 cm to - 3 cm from the floor/below-track height)




# 6\_Segno




Indicate presence, position and size of tiles (A1 - A2)

Single



Double







# 6\_Segno Recessed tracks

It is possible to install the rails in plasterboard ceilings after installing the appropriate carter.


## 1-way recessed track




Width calculations  
 $W \text{ panel} = W \text{ door space} + 3 \text{ cm}$   
 Height calculations  
 $H \text{ panel} = H \text{ Floor/Under-rail (see page 67)} - 1,8 \text{ cm}$




## 2-way recessed track




Width calculations  
 $W \text{ panel} = W \text{ door space} + 8,5 \text{ cm} : 2$   
 Height calculations  
 $H \text{ panel} = H \text{ Floor/Under-rail (see page 67)} - 1,8 \text{ cm}$




## 3-way recessed track




Width calculations  
 $W \text{ panel} = W \text{ door space} + 14 \text{ cm} : 3$   
 Height calculations  
 $H \text{ panel} = H \text{ Floor/Under-rail (see page 67)} - 1,8 \text{ cm}$



## 4-way recessed track





Width calculations  
 $W \text{ panel} = W \text{ door space} + 19,5 \text{ cm} : 4$   
 Height calculations  
 $H \text{ panel} = H \text{ Floor/Under-rail (see page 67)} - 1,8 \text{ cm}$




# 6\_Segno

Dimensions for recessed tracks




## Carter dimensions


1-way Carter




2-way Carter



3-way Carter





4-way Carter




# 6\_Segno Technical specifications

- 1. Trolley
- 2. Door frame profile in aluminum
- 3. Track
- 4. Glass on two sides, 0,5 cm thick.  
Wood/lacquered panel 3,8 cm thick.  
Glass panel weight cm 27 kg/m<sup>2</sup>.  
Wood panel weight 14 kg/m<sup>2</sup>.

## Maximum height and width dimensions





**Available finishes**

**Panel profiles**

AL31 Anodized Aluminium  
 AL32 Polished chrome  
 AL34 Satin steel  
 LC01 Lacquer Bianco  
 LC02 Lacquer Nero  
 LC12 Lacquer Panna  
 LC14 Lacquer Caffè  
 LC15 Lacquer Lino  
 LC16 Lacquer Tortora  
 RAL Lacquered

**Polished double-sided glasses**

SR30 Bianco  
 SR31 Lino  
 SR32 Ardesia  
 SR44 Nero  
 SR50 Tortora  
 SR51 Castagna  
 RAL Colours

**Etched double-sided glasses**

AR30 Bianco  
 AR31 Lino  
 AR32 Ardesia  
 AR44 Nero  
 AR50 Tortora  
 AR51 Castagna  
 RAL Colours

**Wood panel / Lacquered**

LE27 Bleached oak  
 LE28 Wengè-stained oak  
 LE29 Teak  
 LE31 Smoked Chestnut  
 LE32 Black Walnut  
 LE33 European Walnut  
 LE34 Grey stained oak  
 LC01 Lacquer Bianco  
 LC02 Lacquer Nero  
 LC12 Lacquer Panna  
 LC14 Lacquer Caffè  
 LC15 Lacquer Lino  
 LC16 Lacquer Tortora  
 RAL Lacquered  
 GR Raw with primer

**Mirror**

SP01 Clear mirror  
 SP21 Fumè mirror  
 SP22 Bronzo mirror


**1 wood side (LE, LC), 1 glass side**  
**1 wood side (LE, LC), 1 mirror side**  
**1 glass side, 1 mirror side**

# 6\_Segno Sliding track systems


## Tracks

Tracks and strips in aluminium can have a total maximum length of 580 cm, while wood strips will have a maximum length of 300 cm and for longer lengths they will be in multiple pieces. When checking the floor-to-ceiling measurement, it is recommended to take two or three measurements also in the central part of the composition and communicate all the dimensions found. For fixing the sliding systems, it is recommended to use the most suitable system based on the structural characteristics of the ceiling and/or wall. Specify whether the beam must be closed at the ends.

System with recessed track




System with track and covering strips




# 6\_Segno Ceiling tracks

with aluminium strip

1-way tracks





with wood strip (FA/SU)





To determine panel H:  
H floor / ceiling - 5,8 cm

2-way tracks



To determine panel H:  
H floor / ceiling - 5,8 cm

3-way tracks



To determine panel H:  
H floor / ceiling - 5,8 cm



# 6\_Segno Wall tracks

with aluminium strip


with wood strip (FA/SU)

1-way tracks



To determine the total composition H:  
H panel + 5,5 cm



Wall fixing mode



2-way tracks



To determine the total composition H:  
H panel + 11,7 cm